



EASY ASSEMBLY. BUILT TO PERFORM.

Assembled in Minutes. No Special Tools.

STEP 1

START FLAT

Each rack ships flat-packed for efficient transport. All components are included.



Flat-packed design for easy handling and transportation.

www.coreracks.ca



EASY ASSEMBLY. BUILT TO PERFORM.

Assembled in Minutes. No Special Tools.

STEP 2

ADD BRACES

Attach the cross braces to both side panels. No special tools required.



Cross braces lock the side panels in place for strength and stability.

www.coreracks.ca



EASY ASSEMBLY. BUILT TO PERFORM.

Assembled in Minutes. No Special Tools.

STEP 3

Place another panel about **36"** away from the panel with the cross bracing.

Feet to feet.



Correct spacing ensures proper alignment and a strong, stable build.

www.coreracks.ca



EASY ASSEMBLY. BUILT TO PERFORM.

Assembled in Minutes. No Special Tools.

STEP 4

RAISE AND STAND IT UP

Lift panels and connect with bolts and nuts provided, hand tighten then tighten once all the braces are in place.



Make sure the rack is upright, level, and secure before moving to the next step.

www.coreracks.ca

